Introduction

We have come up with this method of allowing you to produce a reasonably accurate model of your chosen size of SPADE anchor. Whilst the construction of this model is time consuming, we are sure that you can appreciate that it is easier and cheaper than sending models around the country. If you have problems in constructing a model, please do not hesitate to contact us for assistance on 01534 739594.

We have chosen A4 paper as this is the most common paper size.


Template Instructions

- 1. Print **pdf** file onto A4 paper. (Make sure that your printer settings are set to print at 100%)
- Arrange sheets so that all reference letters and numbers line up. Don't be surprised if there are gaps, most printers can't print to the edge of the page.
- Tape all sheets together.
- Cut out the template.
- 5. Place on suitable sized cardboard and trace around.
- Cut out cardboard sections (solid lines only ———).
- 8. Score and fold along dashed lines (__ _).
- 9. Cut out the main slot in blade and in tab.
- 10.Pierce holes in side sections and the main anchor shaft.
- 11. Insert tab into tab slot to make blade into a 3D triangular shape.
- 12.Insert anchor shaft into main slot and secure wit a cable tie or string fed through the three holes. Tighten until the blade takes on a concave shape.
- 13. Your model anchor is now complete.

This model is intended as an approximate interpretation of the true dimensions of the anchor. It may also be used to judge whether or not the SPADE will suit your particular application, but no responsibility will be accepted if the real anchor fails to match up exactly.

للج


意じょう



A→



◆A






Model 100


Model Making Instructions

- Cut out templates.
- Place on to suitable sized cardboard and trace around.
- Also transfer dotted/dashed lines onto cardboard.
- Cut out cardboard sections (solid lines only ———).
- Crease the main blade section along segmented dotted line (= . =).
- Score and fold along dashed lines (—).
- Cut out main slot in blade and in tab.
- 8. Pierce holes in side sections and the anchor shaft.
- 9. Insert tab into tab slot to make blade into a 3D triangular shape.
- 10. Insert anchor shaft into main slot and secure with a cable tie or string fed through the three holes. Tighten until the blade takes on a concave shape.
- Your model anchor is now complete.

This model is intended as an approximate interpretation of the true dimensions of the anction. It may be used to judge whether or not the SPADE will suit your particular application, but no responsibility will be accepted if the real anchor fails to match up exactly.







1


o or the state of the state of


A CONTRACTOR OF THE PARTY OF TH


ã


; .7-₁

横。









- 4 to 150 to

ं अवस्थितिहा


100

ing spirit





6 **+**





8 **+**